

CJ7 Only - Wrangler Adjustment on next page

Tools Needed

1/8", 7/32", 5/32", 3/8" Drill Bits
 Flat Screwdriver
 and Drill Motor
 Phillips Screwdriver
 Center Punch
 Hammer
 1/8" Allen Wrench
 7/16" Wrench
 Adjustable Wrench
 10" Tape Measure
 #20 Torx
 Ratchet
 #40 Torx (may be required for some models)

Warning: Improper windshield adjustment will result in poor fitting top and doors, causing looseness or undue strain on the top.

CJ7 Windshield Adjustment: If necessary, loosen the two screws in the Windshield Clamps at the base of the windshield on each side of the vehicle. Adjust the windshield forward or back, use a shim if needed to position the windshield, and tighten the screws.

Windshield Measurement

Before installing the top, check the windshield measurement. The distance from the top lip of the windshield to the top outer edge of the body must be 75 1/8" on both sides of the vehicle. Measure from 6" inside the doors.

Step One

CJ7: After adjusting the windshield, install the Windshield Brackets. Place the Windshield Brackets flush with the frame on the upper corners of the windshield. Use the bracket as a template to mark, center punch and drill two 5/32" holes for each bracket. Mount each bracket to the windshield frame using two #10 x 1/2" Pan Head Sheet Metal Screws.

Note: It may be necessary to loosen or remove the sun visor bolts in order to get the Windshield Bracket underneath.

