

## Step Eight

With the bow halves lying on the rear of the vehicle body, start the male end of one assembly into the female end of the other assembly until they snap together. Rotate the Front Bow forward and slip the Vertical Rods into the Vertical Retainer Mounts. Attach the Horizontal Rod to the Windshield Bracket. Make sure that the pin on the fastener is through the hole in the Windshield Bracket and turn the fastener to lock in place.

